



# Multi with grid connected converter for solar and/or wind turbine


RENEWABLE




VE Configure settings




Activate programmable relay



Set maximal charge voltage / time



Set charge interval delay



Set frequency shift to disconnect grid-converter